

# SUB 9019-AS



1 SUB



2 SUBs Stack\*



3 SUBs Stack\*

| TOPS      | TOPS NUMBER |       |       |  |
|-----------|-------------|-------|-------|--|
| HDL 6-A   | 1 - 4       | 2 - 4 | 3 - 4 |  |
| HDL 10-A  | 1 - 4       | 2 - 4 | 3 - 4 |  |
| HDL 20-A  | 1 - 4       | 2 - 4 | 3 - 4 |  |
| HDL 26-A  | 1 - 4       | 2 - 4 | 3 - 4 |  |
| HDL 28-A  | 1 - 4       | 2 - 4 | 3 - 4 |  |
| HDL 30-A  | 1 - 4       | 2 - 4 | 3 - 4 |  |
| ART 910-A | 1           | •     | •     |  |
| ART 912-A | 1           | •     | •     |  |
| ART 915-A | 1           | •     | •     |  |
| ART 932-A | 1           | •     | •     |  |
| ART 935-A | 1           | •     | •     |  |
| ART 945-A | 1           | 1     | •     |  |
| NX 910-A  | 1           | •     | •     |  |
| NX 912-A  | 1           | •     | •     |  |
| NX 915-A  | 1           | •     | •     |  |
| NX 932-A  | 1           | •     | •     |  |
| NX 945-A  | 1           | 1     | •     |  |
| NX 985-A  | 1           | 1     | •     |  |
| NXL 14-A  | 1           | •     | •     |  |
| NXL 24-A  | 1 - 2       | 1 - 2 | •     |  |
| NXL 44-A  | 1 - 2       | 1 - 2 | •     |  |
| NXW 44-A  | 1           | 1     | •     |  |
| KX 515-A  | 1           | •     | •     |  |
| KX 08-A   | 1           | •     | •     |  |
| KX 10-A   | 1           | •     | •     |  |
| KX 32-A   | 1           | 1     | •     |  |
| KX 45-A   | 1           | 1     | •     |  |
| KXL 4-A   | 1           | 1     | •     |  |
| KXW 4-A   | 1           | 1     | •     |  |

## NOTES

- The ACE presets list is being updated over time; all the configurations shown will be available by Q1 2026
- All line array stacks include a STRAIGHT configuration and a CURVED configuration - RDTap PRESET with STRAIGHT EQ or CURVED EQ
- All presets are valid for both VERTICAL and HORIZONTAL configurations of SUB 9029-A and SUB 9019-A
- (\*) SUB Modules ≥ 2 can be configured as omni (all front-facing) or cardioid, with one rear-facing module.